



BRAKE WINCHES

Safety Information

DO the following:

Read carefully and comply with the guidelines set forth in the Owner's Manual.

Keep hands away from the drum, gears, wire cable, and other moving parts of the equipment.

Keep all unnecessary personnel away from the winch while in operation.

Keep out of the path of the load should the wire cable break and snap back and cause injury.

Ensure cables or webbing is correctly secured before using these winches.

Always ensure the winch is securely attached to the structure and that the structure is capable of withstanding the intended load before operating the winch.

Self-actuating brake requires a minimum of 18kg to operate safely.

These winches are meant for lifting. Not to be used for pulling.

DO NOT do the following:

Do not lift people, or objects over people. Do not walk or work under a load or in the line of force of any load.

Do not exceed the load rating of the winch or any other component in the system. To do so could result in failure of the equipment.

Do not use more than one winch to move a load that exceeds the load rating of a single winch. A shift in load weight could overload the equipment.

Do not use damaged or malfunctioning equipment. To do so could result in failure of the equipment.

Do not modify the equipment in any way. To do so could cause equipment failure.

Do not lubricate (oil or grease) the braking mechanism of the brake winch.

Do not apply a load on the winch with the wire cable / fibre rope fully extended. Keep at least three full turns of cable / fibre rope on the drum.

Do not wrap the wire cable / fibre rope around the load. This may damage the wire cable / fibre rope and could cause the load to fall. Use a sling or other approved lifting device.

Do not operate the winch with guards removed or improperly installed.

Do not divert your attention from the operation. Stay alert to the possibility of accidents, and try to prevent them from happening.

Do not jerk or swing the load. Avoid shock loads by starting and stopping the load smoothly. Shock loads overload the equipment and may cause damage.

Do not leave a suspended load unattended unless specific precautions have been undertaken and keep people away from the winch and out from under the load.

Please note that all goods are supplied by the Advansa to the Customer for use only in applications and purposes for which they were originally designed. Advansa is not liable for any consequential loss whatsoever from improper or inappropriate use of the goods supplied, where the goods are used for purposes beyond or outside of the scope of application for which they were designed and which exceeds their designed performance limit. At all times please consult Advansa if unsure of the suitability of the goods for your intended application.

***Should any difficulties be encountered, please contact our customer service department on +61 8 8243 9100

